

Spring Loaded Drying Rack



Educational Products Inc.

...making teaching a little easier

If parts are missing or you experience problems, please call:

1-800-267-8494

Have your packing slip ready for reference

or email info@copernicused.com




Contents of Box



x 1



bent feet
x 2



hex key
x 1



M6 x 45mm (large)
bolt
x 4



caster stretcher
x 1



M8 hex nuts
x 4



M6 lock washer
x 6



2" threaded
stem caster
x 2



M6 (small) hex nut
x 4



M6 x 30 (small) bolt
x 2

Spring Loaded Drying Rack


Note: metric hardware

WARNING

DO NOT REMOVE THE TIE AROUND RACK UNTIL FULLY ASSEMBLED

Assembly:

1. With rack on it's side, bolt the bent feet to the bottom of the frame with the large bolts, lock washers and nuts with hex key included.
2. Bolt caster stretcher to the bent feet using the remaining two small bolts and lock washers.
3. Insert threaded stem caster, with hex nut on either side, into the caster stretcher.
4. If the rack does not roll properly, the caster height can be changed by adjusting the nuts.



My idea of education is to unsettle the minds of the young and inflame their intellects.

ROBERT MAYNARD HUTCHINS

In everyone's life at some time our inner fire goes out. It is then burst into flame by an encounter with another human being. We should all be thankful for those people who rekindle the inner spirit.

ALBERT SCHWEITZER

Nothing has a better effect upon children than praise.

SIR PHILIP SIDNEY

*Only when total assembly is complete — tighten all bolts.