
## **Disassembly Instructions**

Maestro Chair, Matrix Chair

Material Type: A . Steel B. Plastic





- 1. Press in the clips which hold the backrest to the chair frame through the holes in the rear of the backrest and lift off the
- 2. Remove the pal-nuts holding the seat onto the chair frame and remove the stacking bumpers and seat.
- 3. Remove the glides attached to the bottom of the chair

- 1. Disassembly time: 5-10 minutes
- 2. This procedure assumes basic familiarity with hand tools and furniture terminology: no specialized training is required
- 3. All materials removed and disassembled shall be sorted and segregated with like materials and disposed of or recycled according to recycling availability or waste acceptance
- 4. For items to be recycled, refer to KI's End of Life Recycling Matrix and KI's End of Life Recovery Options Matrix, available



KI · 1330 Bellevue Street · P.O. Box 8100 · Green Bay, WI 54308-8100 · 1-800-424-2432 · www.ki.com