



SECTION 10 28 00
ASCENT 70 UNIVERSAL CHANGING STATION – 80HS0106

Sova offers a wide range of baby and adult changing stations meeting all applicable ASTM and A.D.A requirements when properly installed. Delete options and models not required for your project and modify to your project needs.

PART 1 GENERAL

1.1 SECTION INCLUDES

- A. Diaper changing stations.
- B. Toilet Accessories

1.2 SUBMITTALS

- A. Product Data: Manufacturer's data sheets on each product to be used, including:
 - 1. Preparation instructions and recommendations.
 - 2. Storage and handling requirements and recommendations.
 - 3. Installation methods.
 - 4. Maintenance data / cleaning instructions.

1.3 DELIVERY, STORAGE, AND HANDLING

- A. Store products in manufacturer's unopened packaging until ready for installation.

1.4 PROJECT CONDITIONS

- A. Maintain environmental conditions (temperature, humidity, and ventilation) within limits recommended by the manufacturer for optimum results. Do not install products under environmental conditions outside manufacturer's recommended limits.

1.5 WARRANTY

- A. Warranty: Provide manufacture's standard limited 5-year warranty. All warranties are effective from the date of initial shipment from the manufacturer.

PART 2 PRODUCTS

2.1 MANUFACTURERS

- A. Acceptable Manufacturer: The Sova Company
- B. Substitutions: Not permitted.

2.2 UNIVERSAL CHANGING TABLES

- A. Ascent 70 Universal Changing Station is designed and engineered to meet the standards of the ICC A 117.1 2017 with Supplement 1 (Section 613) and Buy America Build America (BABA) Act, passes UL 962, CSA2202 No. 68, IK10 and IPX6 testing. Include ANSI warning labels.
- B. Universal Changing Table:
 - 1. Product: 80HS0106 – Ascent 70 Universal Changing Station as manufactured by The Sovia Company.
 - a. Changing surface extends 37 inches (940 mm) from the wall in an open position.
 - b. Required mounting surface 69 inches (1753 mm) high by 70.25 (1785 mm) wide.
 - c. Constructed of heavy-duty steel, type 304 brushed stainless steel and ABS is rated to support a static load of 500lb (227 kg).
 - d. Patent Pending mounting solution and Electronic Spline (E-Spline) automatic tray raising safety feature.
 - e. Replaceable high-hygiene ABS tray.
 - f. Dual pneumatic gas shocks provide easy and safe open/close operation.
 - g. Two independent buttons to easily raise and lower height of the tray for easy changing (located on the front of the tray and right side of the shroud for easy access)
 - h. Indicator lights and sound offer an extra layer of safety assurance for the impaired.
 - i. When closed, unit projects 9.5 inch (241 mm) from wall.
 - j. Two-hand operation safety guard.
 - k. Included battery back-up.
 - l. Plug-in to GCFI outlet or hardwire 120V / 60W
 - m. Easily mounted to standard load bearing wall.

PART 3 EXECUTION

3.1 EXAMINATION

- A. Do not begin installation until substrates have been properly prepared.
- B. If substrate preparation is the responsibility of another installer, notify the Architect of unsatisfactory preparation before proceeding.

3.2 PREPARATION

- A. Clean surfaces thoroughly prior to installation.
- B. Prepare surfaces using the methods recommended by the manufacturer for achieving the best result for the substrate under the project conditions.
- C. Ensure baseboards are cut per manufacturers specification.

3.3 INSTALLATION

- A. Install in accordance with manufacturer's instructions.

3.4 PROTECTION

- A. Protect installed products until completion of the project.
- B. Touch-up, repair or replace damaged products before Substantial Completion. [END]



SECTION 10 28 00
ASCENT 76 UNIVERSAL CHANGING STATION – 80HS0206

Sova offers a wide range of baby and adult changing stations meeting all applicable ASTM and A.D.A requirements when properly installed. Delete options and models not required for your project and modify to your project needs.

PART 1 GENERAL

1.1 SECTION INCLUDES

- A. Diaper changing stations.
- B. Toilet Accessories

1.2 SUBMITTALS

- A. Product Data: Manufacturer's data sheets on each product to be used, including:
 - 1. Preparation instructions and recommendations.
 - 2. Storage and handling requirements and recommendations.
 - 3. Installation methods.
 - 4. Maintenance data / cleaning instructions.

1.3 DELIVERY, STORAGE, AND HANDLING

- A. Store products in manufacturer's unopened packaging until ready for installation.

1.4 PROJECT CONDITIONS

- A. Maintain environmental conditions (temperature, humidity, and ventilation) within limits recommended by the manufacturer for optimum results. Do not install products under environmental conditions outside manufacturer's recommended limits.

1.5 WARRANTY

- A. Warranty: Provide manufacture's standard limited 5-year warranty. All warranties are effective from the date of initial shipment from the manufacturer.

PART 2 PRODUCTS

2.1 MANUFACTURERS

- A. Acceptable Manufacturer: The Sova Company
- B. Substitutions: Not permitted.

2.2 UNIVERSAL CHANGING STATION

- A. Ascent Universal Changing Station is designed and engineered to meet the standards of the ICC A 117.1 2017 with Supplement 1 (Section 613) and Buy America Build America (BABA) Act, passes UL 962, CSA2202 No. 68, IK10 and IPX6 testing. Include ANSI warning labels.
- B. Ascent 76 Universal Changing Station:
 - 1. Product: 80HS0206 – Ascent 76 Universal Changing Station as manufactured by The Sova Company.
 - a. Changing surface extends 40 inches (1016 mm) from the wall in an open position.
 - b. Required mounting surface 69 inches (1753 mm) high by 76.6 (1946 mm) wide.
 - c. Constructed of heavy-duty steel, type 304 brushed stainless steel and ABS is rated to support a static load of 500lb (227 kg).
 - d. Patent Pending mounting solution and Electronic Spline (E-Spline) automatic tray raising safety feature.
 - e. Replaceable high-hygiene ABS tray.
 - f. Dual pneumatic gas shocks provide easy and safe open/close operation.
 - g. Two independent buttons to easily raise and lower height of the tray for easy changing (located on the front of the tray and right side of the shroud for easy access)
 - h. Indicator lights and sound offer an extra layer of safety assurance for the impaired.
 - i. When closed, unit projects 9.5 inch (241 mm) from wall.
 - j. Two-hand operation safety guard.
 - k. Included battery back-up.
 - l. Plug-in to GCFI outlet or hardwire 120V / 60W
 - m. Easily mounted to standard load bearing wall.

PART 3 EXECUTION

3.1 EXAMINATION

- A. Do not begin installation until substrates have been properly prepared.
- B. If substrate preparation is the responsibility of another installer, notify the Architect of unsatisfactory preparation before proceeding.

3.2 PREPARATION

- A. Clean surfaces thoroughly prior to installation.
- B. Prepare surfaces using the methods recommended by the manufacturer for achieving the best result for the substrate under the project conditions.
- C. Ensure baseboards are cut per manufacturers specification.

3.3 INSTALLATION

- A. Install in accordance with manufacturer's instructions.

3.4 PROTECTION

- A. Protect installed products until completion of the project.
- B. Touch-up, repair or replace damaged products before Substantial Completion.

END OF SECTION