














Chevron Desk

Assembly Instructions



Assembly Instructions

Chevron Desk

Part	Drawing	Description	Qty	Part	Drawing	Description	Qty												
P1		Table Top	1 EA	<div style="border: 1px solid black; border-radius: 15px; padding: 10px; text-align: center;"> <p>Hardware List</p> <table style="width: 100%; border-collapse: collapse;"> <tr> <td style="width: 5%; text-align: center;">A</td> <td style="width: 15%; text-align: center;"></td> <td style="width: 50%;">M6*12mm Screw</td> <td style="width: 30%; text-align: right;">9 EA</td> </tr> <tr> <td style="text-align: center;">B</td> <td style="text-align: center;"></td> <td>Glide</td> <td style="text-align: right;">3 EA</td> </tr> <tr> <td style="text-align: center;">C</td> <td style="text-align: center;"></td> <td>Allen Wrench</td> <td style="text-align: right;">1 EA</td> </tr> </table> </div>				A		M6*12mm Screw	9 EA	B		Glide	3 EA	C		Allen Wrench	1 EA
A		M6*12mm Screw	9 EA																
B		Glide	3 EA																
C		Allen Wrench	1 EA																
P2		Upper Leg	3 EA																
P3		Insert Leg	3 EA																


We recommend that you assemble this unit on a table.

Chevron Desk

Assembly Instructions

READ THROUGH INSTRUCTIONS FROM BEGINNING TO END BEFORE STARTING TO ASSEMBLE UNIT.

- 1.) Identify and separate all the parts and hardware.
- 2.) Place the Table Top (P1) face down on a padded surface. Slide one of the Upper Leg (P2) under the wing flanges on one of the top mount plates that are attached to the bottom of the Table Top (P1) as shown in Illustration #1. Secure in place using one Screw (A). Tighten Screw with Allen Wrench (C).



- 3.) Repeat Step 2 to install the other two legs.
- 4.) Screw in Glide (B) into the threaded hole in the bottom of each Insert Leg (P3). Place an Insert Leg (P3) into each Upper Leg (P2) and secure using two Screws (A) at your desired height as shown in Illustration # 2. Tighten the Screws (A) using Allen Wrench (C).

