


**551-510 Baseball Backstop without Hood**  
**551-511 Baseball Backstop with Hood**

Page 1  
Rev 06/18/03

**IMPORTANT**

Please retain this instruction sheet in your files. It contains important maintenance instructions, as well as replacement parts information.



**551-510 WITHOUT HOOD**

1	CTN		Hardware Bag
9	WF	553-351	Panels
4	PIPE	553-601	2 3/8" OD x 19'0"
			<b><u>HARDWARE BAG</u></b>
4		105-017	2 3/8" Pipe Plug
24 pr		551-511	1" x 1" Saddle Clamps
36 pr		555-512	1" x 2 3/8" Saddle Clamps
72		126-505	5/16" x 1 1/4" Carriage Bolts
24		116-504	5/16" x 1" Hex Bolts
96		326-501	5/16" Lock Washers
96		216-501	5/16" Hex Nuts
1		416-400	1/4" Socket Key

**551-511 WITH HOOD**

1	CTN		Hardware Bag
4	PIPE	553-601	2 3/8" OD x 19'0"
2	PIPE	553-204	Hood Support
2	WF	553-352	Panel
10	WF	553-351	Panel
			<b><u>HARDWARE BAG</u></b>
4		105-017	2 3/8 OD Pipe Plugs
36 pr		555-511	1" x 1" Saddle Clamps
44 pr		555-512	1" x 2 3/8" Saddle Clamps
88		126-505	5/16" x 1 1/4" Carriage Bolts
36		116-504	5/16" x 1" Hex Bolts
124		326-501	5/16" Lock Washers
124		216-501	5/16" Hex Nuts
2		196-803	1/2" x 3/4" Socket Set Screw
1		416-500	1/4" Socket Key

1 CTN    9 PANEL    4 PIPE  
14 Total Pcs.    730# Weight    CLASS 70

1 CTN    12 PANEL    6 PIPE  
19 Total Pcs.    850# Weight    CLASS 70

**551-510 Baseball Backstop without Hood**  
**551-511 Baseball Backstop with Hood**

Page 2  
Rev 06/18/03

**TOOLS NEEDED FOR THE JOB:**

Post Hole Digger	Crescent Wrench
Level	5/16" Socket Wrench
10 cu. ft. of Pre-Mix Concrete	

**GENERAL ASSEMBLY INSTRUCTIONS**

1. Check each piece carefully and remove any sharp projections that may have been caused by shipping.
2. DO NOT Tighten nuts more than hand-tight until the entire assembly is completed.
3. All threaded ends of bolts protruding beyond nuts should be cut off and peened over to remove any sharp edges.

**SPECIFIC ASSEMBLY INSTRUCTIONS:**

1. Mark and dig footing holes as shown below.
2. Assemble one center section of backstop on ground with bottom of upright posts at the front edge of the footing holes.
3. Hand-tighten all bolts securely.
4. Raise assembly into position in footing holes.
5. Assemble each additional section in a similar manner. Raise and attach to sections already in place.
6. **(for 551-511 model only)** Add hood sections.
7. Plumb and level backstop. Tighten all bolts securely.
8. Pour footings. Place bricks or old cement chunks below the posts to allow wet cement under the post.
9. Allow 48 hours for concrete to dry before using the equipment.

**MAINTENANCE:**

Check periodically for loose bolts and broken parts. Tighten and/or replace immediately.

